sector 111

S111 Seat Grommets Installation Instructions

Rev. A

Page 1 of 5

Assembly Step

Tools/ Parts

Detailed Instructions

Picture/ Illustration

READ FITTING INSTRUCTIONS IN FULL BEFORE INSTALLATION

This article is sold without warranty expressed or implied. No warranty or representation is made as to this product's ability to protect the user from injury or death. The user assumes that risk. The effectiveness, warranty and longevity of this equipment are directly related to the manner in which it is INSTALLED, USED, and/or MAINTAINED. THE USER ASSUMES THE RISK.

By purchasing this product and opening the packaging, purchasers expressly acknowledge, understand and agree that they take, select and purchase these SECTOR 111 products from SECTOR 111, its affiliates, distributors, and agents (collectively, SECTOR 111) **as is** and **with all faults**.

The entire risk as to the quality and performance of these SECTOR 111 parts is with the purchasers. Working on your car can be a dangerous activity. If you are unsure of what you are doing, please leave mechanical or Safety critical work to a skilled mechanic.

We take no responsibility for the incorrect use and/or installation of SECTOR 111 products.

CAUTION: Fiberglass particles will be generated during this modification. Wear eye protection, a particulate filtration mask, long sleeve/long pants to ensure that particles are not introduced to your body.

Assembly Step	Tools/ Parts	Detailed Instructions	Picture/ Illustration
1. Position Grommets on Seat	Seat Grommet	a. Place grommet in position as shown.b. Note: Be sure not to place in head rest reinforced area.	
2. Mark Grommet Position on Seat	Seat GrommetPencil	 a. Trace the inner hole of the grommet with a pencil. b. Although this isn't the final size, it will help in positioning your cut. c. Repeat for other side ensuring that both sides are spaced the same and look even. 	
3. Make First Cuts	 Compressed Air Source Air Die Grinder 3 "Cut Off Wheel 	 a. Cut out roughly with cut off wheel, still leaving your pencil lines showing. b. This will give you a good feel for cutting before your final cuts. c. Be careful not to cut through the leather on front of seat. 	

Assembly Step	Tools/ Parts	Detailed Instructions	Picture/ Illustration
4. Mark Actual Grommet Position	• Pencil	 a. Now you can free hand in another line with your pencil about 3/16in. larger than your earlier marks. b. Do a quick overlay with grommet making sure you are checking size with the larger side of grommet. 	
5. Second Cuts	 Compressed Air Source Air Die Grinder 3" Cut Off Wheel 	a. Now cut again with cut off wheel just short of your marks.	
6. Finish Cuts	 Dremmel Tool Sid Cutting Burr 	a. Now switch to a more accurate cutting tool like a Dremmel and work up to your lines checking fit as you go.	

S111 Seat Grommet Instructions

Rev. A

Page 4 of 5

Assembly Step	Tools/ Parts	Detailed Instructions	Picture/ Illustration		
		b. Once grommet fits through hole you are done cutting fiberglass.			
7. Trim Seat Foam	Razor Blade	a. Now cut out the remaining seat foam only.b. Be sure not to cut the leather!			
8. Cut Leather	Razor Blade	a. Cut out an "X" in the leather as shown.			

Assembly Step	Tools/ Parts	Detailed Instructions	Picture/ Illustration
9. Insert Grommet Front	 Grommet Razor Blade	a. Try pressing grommet through slowly.b. Relieve leather more if needed.c. After grommet is through, cut off extra leather.	
10. Insert Grommet Back	• Grommet	a. Now press other half of grommet into first half and snap them together.	
		b. This is what the finished seat should look like.	sector III