VWNavi - DIY: How to install MFD into Golf/Jetta/Bora with Double-Din (DD) radio



	VWNavi > VAG Factory fit Navigation Systems > Navi MFD Forum DIY: How to install MFD into Golf/Jetta/Bora with Double-Din (DD) radio						Remember Me?
ĺ	Register	FAQ	Members List	Calendar	Т	oday's Posts	Search 🔻



### 07-22-2004, 08:13 AM

# GTi 1.8Turbo Registered User Gold Member



Join Date: Feb 2004 Location: Denver, CO. USA Posts: 1,390

# DIY: How to install MFD into Golf/Jetta/Bora with Double-Din (DD) radio


**NOTE**: This installation is for all Golf/Jetta/Bora (Sedan or Avant) with Double-Din radio <u>ONLY</u> ("Premuim 6" in USA or "Delta 6" in Europ)

## Parts needed:

1- Double-Din/MFD radio Removal tools (T10057)



2- Double-Din "plug-n-play" adapter.



3- Bosch (or similar) GPS antenna.




- 4- Torx tool set.
- 5- Telephone wire tap connectors from RadioShack (64-3081).



6- Tap-In squeeze connectors from RadioShack (64-3035).













3- Remove the right side now by unscrewing two bolts. Note that one bolt is will be visible after you remove the left side (step#2), after you remove the two bolts, simply pull it:

#### VWNavi - DIY: How to install MFD into Golf/Jetta/Bora with Double-Din (DD) radio



4- Remove this metal. It's a good idea to mark the screw places before you remove them. Also, notice there are two types of screws depend on the location. Make a note of that also.



5- Pull the trim piece behind the cluster. After that, remove the cluster after you unscrew the two screws. Unplug the Blue and Green connectors by pushing the purple tap upwards with a flat screwdriver.

**NOTE**: If you unplugged the connectors while the key is in ignition, you <u>*WILL*</u> get the Airbag fault light. You need a Vag-Com or visit your dealer to remove that fualt code!!!






6- Remove your Double-Din radio (with the correct removal tools) and disconnect all the connectors in the back.



7- (optional step) If you want to make the CD changer adapter, click here.

8- Put the GPS antenna on the metal behind the cluster, it will stick right away. After that run the wire to the back of your MFD. Once it's done, zip ties the long wire behind the steering wheel metal. Make sure your steering wheel can be moved easily all ways. Also, make sure you have enough length of GPS antenna wire in the back of your MFD.






9- Plug the "Plug-n-Play" adapter you have between the car original connectors and your MFD. Run the three long wires (Yellow, Red and Orange) to the driver area.

10- Plug the GPS antenna into the back of your MFD.


11- After you are done with the wires in the back of your MFD, you can put the MFD into its final place. Note that it could be difficult to push the MFD all the way in with all these wire. Try to push all the wires down where your A/C controls are. It gave me more room by doing this and the MFD slides easier now.

12- You need to connect three wires now and you are done. I'd connect the GALA wire first. Connect the Yellow wire that came from the "plug-n-play" adapter to the White wire with Blue strip (White/Blue) in the **Blue** connector. Note that in some 2003+, VW uses diffrent colors. It should be in the same location (pin#3).





Do NOT use this type of connector for GALA wire in the back of your cluster (Blue connector pin#3)!!!

Most likely, you will NOT get any GALA signal to your MFD!!!



13- Now connect the other two wires to the headlight switch. Connect the Orange wire to pin#17 of the headlight switch and the Red wire to pin1 to the headlight switch as well.





14- Turn on your MFD and put the PIN code. After the correct code is entered, make sure to see if your MFD lights work when your lights on. See if the dimmer work as well. Also, check if your MFD turns on/ off with your key as your old radio do.

15- I'd take a 10 minutes test drive before put back the knee bolster. Note that your MFD will NOT work right away. It needs few minutes to calibrate it self. After about 5~10 minutes of driving, your MFD should be good for now. Don't worry about the MFD setting since your MFD will set it self after few minutes depends on your tire's life.

16- Enjoy your MFD now 🥶



« Previous Thread | Next Thread »

Posting Rules 🛞							
You <b>may not</b> post new threads You <b>may not</b> post replies You <b>may not</b> post attachments You <b>may not</b> edit your posts							
<u>vB code</u> is <b>On</b> <u>Smilies</u> are <b>On</b> [IMG] code is <b>On</b>							

HTML code is Off

Forum Jump

Similar Threads								
Thread	Thread Starter	Forum	Replies	Last Post				
DIY: How to install MFD into Passat with Double-Din (DD) Radio	GTi 1.8Turbo	Navi MFD Forum	59	05-16-2006 10:40 PM				
DIY: How to install MFD into Golf/Jetta/Bora with Single- Din (SD) Radio	GTi 1.8Turbo	Navi MFD Forum	13	02-12-2006 05:00 PM				
Install complete!	gileso	Navi MFD Forum	3	07-31-2004 04:58 PM				
Help!! What do i need to install MFD	Sleeping	Navi MFD Forum	2	07-20-2004 03:45 AM				
Double DIN	nevbull	Navi MFD Forum	1	03-08-2004 07:30 PM				

All times are GMT. The time now is 09:18 PM.

<u> Contact Us</u> - <u>VWNavi</u> - <u>Archive</u> - <u>Top</u>